


2



1

Подключение к MAZDA CX7-CX9



CS9100 (SPT-100)
Mazda (Kenwood)

	CS 9100	CS8000	GARMIN
SW1	ON	ON	ON
SW2	OFF	OFF	OFF
SW3	OFF	OFF	OFF
SW4	OFF	OFF	OFF
SW5	ON	OFF	OFF
SW6	OFF	ON	OFF
SW7	OFF	OFF	ON
SW8	OFF	OFF	OFF



2

1